


use the setting tools to set the work mode. (\Demon(En)\tool\OMMI SETUP

TOOLS.exe)



Two working modes:

1.auto output: don't use any software. just swipe the magnetic card or put rf-card to the induction fields, data will show at the mouse cursor.

2.shut down the "Mag Card Auto-read" and "RFID Auto-Read" click "Set device" ,open the software, if showed succeed means the device and computer have connected.

