

1. Two work modes: HID-mode and auto-output mode (if your machine was ZCS80, please ignore note 1)  
Refer to “tool”->”setting tool” , it will show u how to change work mode.
2. If open the software and shows lack 'TABCTL32.OCX' , please install the “setup.exe” to register the TAB.OCX.
- 3.if opened the software and show “failed” at the top right corner ,that means device was not connect to your computer, please click “connect” and try again. if still can't connect , refer to “doc”->”demo software instruction” the first chapter “initialization” it will show u how to confirm the connection .